


Festool DOMINO's Loose Tenons and Available "PRESETS"

**Tenon Size
Mortise Width
Mortise Depth
Mortise Location**

DOMINO Tenon Sizes



Bit Diameter	Mortise Width Selector Switch values represent preset distance BETWEEN BIT CENTERS		
	Mortise Widths (shown in mm)		
	"13+"	"19+"	"23+"
5mm	18 mm	24 mm	28 mm
6mm	19 mm	25 mm	29 mm
8mm	21 mm	27 mm	31 mm
10mm	23 mm	29 mm	33 mm

DOMINO "tenon" widths shown in gray, Mortise width shown by circles

Mortise Depth of Cut (gray)

