


Chapter 3 Control Panel



Button	Description
RUN STOP	Switch between run and stop state by single press.
STOP RESET	It has different meanings to push this button during different modes: 1. if the inverter is running, it would stop; 2. If a fault happens, the inverter would be reset; 3. If it is operated on menus, it returns to parent menu.
REV	Change the inverter's direction. It also works during the runtime.
SET	Enter menu mode. If it is on item, the data would be saved and lower level menu would be displayed.
▲▲	Change items in the menu or modify the parameter data.
▶▶	Modify the menu content and point move in panel.
Potentiometer	Change runtime frequency.

→ modifier le contenu des menus et déplacer le point dans le panneau